

PRISM PLUS

Thanks to its highly durable PC frame, PRISM PLATINUM offers excellent protection as well as great value for money. Fully recyclable all polycarbonate frame.



1624401 • PLATINUM Clear Lens



1624402 • PLATINUM Smoke Lens

NOW AVAILABLE IN
PLATINUM
ANTI-FOG ANTI-SCRATCH









22 g


- + ULTRA LIGHT WEIGHT & RIMLESS POLYCARBONATE FRAME**
- + SINGLE PIECE 8 BASE, DISTORTION FREE LENS**
- + FULLY RECYCLABLE: ALL POLYCARBONATE FRAME
WITH NO METAL PARTS**
- +  PLATINUM (P) COATING**

bollé
SAFETY

PRISM PLUS

MODEL	VERSIONS	PRODUCT CODE	LENS MARKING	FRAME MARKING	COATINGS
PRISM PLUS	 Clear PLATINUM	1624401	IO & 	AS/NZS 1337.1.2010	Anti-scratch/Anti-fog/Platinum 
	 Smoke PLATINUM	1624402	I3 & 	AS/NZS 1337.1.2010	Anti-scratch/Anti-fog/Platinum 

LENS MARKING

. Platinum is a permanent coating on both sides of the lens giving them a high resistance to scratching (1.4 cd / m²), to the most aggressive chemicals and delays the onset of fogging as per the testing requirements of EN166.

- I. The letter 'I' signifies 'Medium Impact' approval.
- O. The letter 'O' marking signifies that the product has been approved for use both outdoors and indoors. This marking appears on all clear, amber and contrast lenses

OCULAR LENS CATEGORY:

- O. Range of luminous transmittance 80-100% (clear & amber).
- 3. Range of luminous transmittance 8 -18% (smoke & bronze).

APPLICATIONS

- Solar UV exposure
- Emergency response
- Rigging
- Assembly and production work

MAIN MARKETS

- Manufacturing
- Petrochemical
- Construction
- Government
- Mining
- Medical and dental
- Food industry

LENSES

- 2mm polycarbonate
- 8 base curve
- Platinum coating on both sides of lens: Clear and Smoke
- 100% UV 385 – Clear
- 100% UV 400 – Smoke

CLEANING AND STORAGE

CLEANING : Bollé Safety recommends only using our **BOLLÉ CLEAN** Lens cleaning system.

MAINTENANCE: Pitted, scratched or damaged lenses must be replaced by replacing the complete product. If the frame is damaged also replace the complete product. After each use it is recommended to keep the spectacles or goggles in a microfiber pouch or rigid case.

STORAGE: Store between 5 and 40 °, humidity <90%.

CHARACTERISTICS	
LENSES	PC - 2,2 mm - Curve 8
FRAME	PC
TEMPLES	PC
STRAP	Non applicable
FOAM	Non applicable
SPARE LENSES	No

FRAME MARKING

AS/NZS 1337.1.2010 : Tested and approved to AS/NZS 1337.1.2010 for medium impact protection.

ASIA/PACIFIC HEADQUARTERS :

Bollé Australia Pty Ltd
32-40 Fairchild Street
Heatherton VIC 3202
T: 1300 138 098
E: safety@bolle.com.au

NEW ZEALAND:

Bollé New Zealand Limited
Unit 5, 114 Sawyers Arms Road
Papanui, Christchurch 8052
T: 03 3751400
E: bolle@bolle.co.nz